RULE 2012 PROTOCOL-ATTACHMENT D

EQUIPMENT TUNING PROCEDURES

TABLE OF CONTENTS

ATTA	CHMENT D - EQUIPMENT TUNING PROCEDURES	
A.	Procedures	. D-1

EQUIPMENT TUNING PROCEDURES

A. PROCEDURES

Nothing in this Equipment Tuning Procedure shall be construed to require any act or omission that would result in unsafe conditions or would be in violation of any regulation or requirement established by Factory Mutual, Industrial Risk Insurers, National Fire Prevention Association, the California Department of Industrial Relations (Occupational Safety and Health Division), the Federal Occupational Safety and Health Administration, or other relevant regulations and requirements.

- 1. Operate the unit at the firing rate most typical of normal operation. If the unit experiences significant load variations during normal operation, operate it at its average firing rate.
- 2. At this firing rate, record stack-gas temperature, oxygen concentration, and CO concentration (for gaseous fuels) or smoke-spot number 2 (for liquid fuels), and observe flame conditions after unit operation stabilizes at the firing rate selected. If the excess oxygen in the stack gas is at the lower end of the range of typical minimum values, and if CO emissions are low and there is no smoke, the unit is probably operating at near optimum efficiency at this particular firing rate.
- 3. Increase combustion air flow to the furnace until stack-gas oxygen levels increase by one to two percent over the level measured in Step 2. As in Step 2, record the stack-gas temperature, CO concentration (for gaseous fuels) or smoke-spot number (for liquid fuels), and observe flame conditions for these higher oxygen levels after boiler operation stabilizes.
- 4. Decrease combustion air flow until the stack gas oxygen concentration is at the level measure in Step 2. From this level, gradually reduce the combustion air flow in small increments. After each increments, record the stack-gas temperature, oxygen concentration, CO concentration (for gaseous fuels), and smoke-spot number (for liquid fuels). Also observe the flame and record any changes in its condition.
- 5. Continue to reduce combustion air flow stepwise, until one of these limits is reached:
 - a. Unacceptable flame conditions, such as flame impingement on furnace walls or burner parts, excessive flame carryover, or flame instability; or

- b. Stack gas CO concentrations greater than 400 ppm; or
- c. Smoking at the stack; or
- d. Equipment-related limitations, such as low windbox/furnace pressure differential, built in air-flow limits, etc.
- 6. Develop an O2/CO curve (for gaseous fuels) or O2/smoke curve (for liquid fuels) using the excess oxygen and CO or smoke-spot number data obtained at each combustion air flow setting.
- 7. From the curves prepared in Step 6, find the stack-gas oxygen levels where the CO emissions or smoke-spot number equal the following values:

<u>Fuel</u>	<u>Measurement</u>	<u>Value</u>
Gaseous	CO emissions	400 ppm
#1 and #2 oils	smoke-spot number	number 1
#4 oil	smoke-spot number	number 2
#5 oil	smoke-spot number	number 3
Other oils	smoke-spot number	number 4

The above conditions are referred to as the CO or smoke thresholds, or as the minimum excess oxygen level.

Compare this minimum value of excess oxygen to the expected value provided by the combustion unit manufacturer. If the minimum level found is substantially higher than the value provided by the combustion unit manufacturer, burner adjustments can probably be made to improve fuel and air mixing, thereby allowing operation with less air.

- 8. Add 0.5 to 2.0 percent of the minimum excess oxygen level found in Step 7 and reset burner controls to operate automatically at this higher stack-gas oxygen level. This margin above the minimum oxygen level accounts for fuel variations, variations in atmospheric conditions, load changes, and nonrepeatability or play in automatic controls.
- 9. If the load of the combustion unit varies significantly during normal operation, repeat Steps 1-8 for firing rates that represent the upper and lower limits of the range of the load. Because control adjustments at one firing rate may affect conditions at other firing rates, it may not be possible to establish the optimum excess oxygen level at all firing rates. If this is the case, choose the burner control

- settings that give best performance over the range of firing rates. If one firing rate predominates, settings should optimize conditions at that rate.
- 10. Verify that the new settings can accommodate the sudden load changes that may occur in daily operation without adverse effects. Do this by increasing and decreasing load rapidly while observing the flame and stack. If any of the conditions in Step 5 result, reset the combustion controls to provide a slightly higher level of excess oxygen at the affected firing rates. Next, verify these new recorded at steady-rate operating conditions for future reference.